
FT-3ターボタイマーハーネス取付説明書 FT-3(インプレッサ用)ターボタイマーハーネス 4103-RF002

- ●この度は、HKSターボタイマーハーネスをお買い上げいただき誠にありがとうございます。
- ●本製品は、HKSターボタイマーと、キーシリンダーとの間にカプラーオンで接続し、ターボタイマーを取付けるためのハ -ネスです。




<Parts List>



接続方法

- (1) バッテリのマイナス端子のターミナルを取外してください。
- (2) ステアリングコラム及び、周辺内装部品を取外してください。
- (3) キーシリンダーと車両側のハーネスとの間にターボタイマーハーネスを取付けてください。この時、必ずコネク タは奥までしっかり差し込み、ロックがかかっている事を確認してください。(ロックがかかっていないと、ハ ーネスを引っ張っただけで、コネクタが外れてしまいます)
- (4) サイドブレーキアダプタのオスギボシ(灰色線)をターボタイマーのメスギボシ(灰色線)に、サイドブレーキ アダプタのメスギボシ(灰色線)をターボタイマー添付のサイドブレーキリード線(灰色線)のオスギボシに接 続してください。



取付け後の作業

(1) ターボタイマー取付説明書に沿ってターボタイマーの取付け作業を行ってください。

本製品に関するご不明な点等ございましたら、HKSお客様相談室(0544-29-1100)までお問い合わせください。

FT-3 Turbo Timer Harness Installation Manual Part No.**4103-RF002**

• This harness is for the installation of the Turbo Timer by connecting it in between the Turbo Timer and Key Cylinder. Please read the following instructions carefully before installing the harness.

Warning!

•Please remove the negative terminal of the battery before starting with the installation. This will prevent hazards like a short that may result in a fire and damage to the unit.

Installation

- (1) Remove the negative side of the Battery Terminal.
- (2) Remove the steering column along with the interior parts around it.
- (3) Install the Turbo Timer Harness in between the key cylinder and harness of the interior side Make sure the connector is locked in all the way. (If it's not locked in the connector may fall off when pulled on the harness.)
- (4) Connect the male connector of the gray parking brake adapter wire to the female connector on the Turbo Timer. Then connect the female connector of the gray parking brake adapter wire to the male connector of the gray lead wire from the parking brake.

Warning!

•Connecters have to be connected as shown above.

Wrong connection may result in a fire by a short circuit and/or damage electric units.

After the Installation

(1) Follow the instructions of the Turbo Timer and perform the installation of the unit.